

OPTIPOP

Fiber Optic Connector Cassette Cleaning Tool User Manual




For use with US Conec Ltd. part numbers:







US Conec P/N	NTT-AT P/N	Description
6338	ATC-RE-01	Single Slot – No label
6227	ATC-RE-01	Single Slot – With USC Label
6339	ATC-RE-03	MTP Male – No label
6226	ATC-RE-03	MTP Male – With USC Label
6437	ATC-RE-02	Two Slot (LC Duplex) – No Label
6230	ATC-RE-02	Two Slot (LC Duplex) – With USC Label
6340	ATC-RE-04	MTRJ Male – No Label
6228	ATC-RE-04	MTRJ Male – With USC Label
8057	ATC-RE-03W	FTTH OptiTap Plug Connections – No Label

Thank you for your purchase of the OPTIPOP R cassette. This is the latest generation of the fiber optic cassette cleaning tools from NTT-Advanced Technology, the world's leading expert on fiber optic connector cleaning solutions.

The Users Manual includes the instructions on how to properly use OPTIPOP R cassette and instructions on how to replace the cleaning tape. Following these instructions will help you get the best cleaning performance from your OPTIPOP R cassette and the long service life.



How to Clean Connectors	
<p>Step 1: Open the shutter by gripping the lever. The shutter will open and a new section of cleaning tape will be available.</p>	
<p>Step 2: Depress the ferrule on the cleaning tape using same pressure as a writing pen. Move the connector from left to right. When cleaning angled polished connectors (APC), be sure to turn the ferrule so that end face is making contact.</p>	
<p>Step 3: Release the lever to close shutter</p>	

How to Replace The Cassette Reel	
<p>Step 1: Turn the screw with a coin or flat head screw driver. Remove the cassette reel and winding reel.</p>	<p>Step 4: Reinsert the winding reel and cassette reel. Route the cleaning tape over the guide rollers and wiping board.</p>
	
<p>Step 2 : Pull the cleaning tape from the winding reel</p>	<p>Step 5: Re-hook the cover onto the right side of the cassette housing. Re-snap the tab on the left side of the cover</p>
	
<p>Step 3 : Load the new cleaning tape onto the winding reel. Secure it using a bonding tape.</p>	<p>Step 6 : Engage the lever two or three times to verify the cleaning tape is moving smoothly.</p>
	

Caution!

- Only use OPTIPOP R refills manufactured by NTT-Advanced Technology. Failure to use NTT-Advanced Technology manufactured replacement refills may void the warranty.
- Do NOT reuse cleaning tape as this may cause cross contamination and cause permanent damage.
- A new refill is needed when the lever becomes difficult to depress.
- Do not leave the cassette in temperatures exceeding 60°C/140°F for extended periods.
- OPTIPOP R cassettes are warranted for manufacturer and material defects only. Abusive, neglect or use for unintended purposes are not covered not covered in the warranty.

For technical support or re-ordering information, please contact US Conec Ltd at:

customerservice@usconec.com +1.828.323.8883 (international) 1.800.769.0944 (US and Canada)