

## OLC - 01 OTDR Launch Cable

### Description:

If you are installing an outside plant network such as a long distance network or a long campus LAN with splices between cables, you will want an OTDR to check if the fibers and splices are good. The OTDR can see the splice after it is made and confirm it's performance. It can also find stress problems in the cables caused by improper handling during installation. If you are doing restoration after a cable cut, the OTDR will help find the location of cut and help confirm the quality of temporary and permanent splices to restore operation. On singlemode fibers where connector reflections are a concern, the OTDR will pinpoint bad connectors easily.

Since so little of the light comes back to the OTDR for analysis, the OTDR receiver circuit must be very sensitive. That means that big reflections, which may be one percent of the outgoing signal, will saturate the receiver, or overload it. Once saturated, the receiver requires some time to recover, and until it does, the trace is unreliable for measurement.

The most common place you see this as a problem is caused by the connector on the OTDR itself. The reflection causes an overload which can take the equivalent of 50 meters to one kilometer to recover fully, depending on the OTDR design, wavelength and magnitude of the reflection. It is usually called the "Dead Zone". For this reason, most OTDR manuals suggest using a "pulse suppresser" cable, which doesn't suppress pulses, but simply gives the OTDR time to recuperate before you start looking at the fiber in the cable plant you want to test. They should be called "launch" cables.

Do not ever use an OTDR without this launch cable! You always want to see the beginning of the cable plant and you cannot do it without a launch cable. It allows the OTDR to settle down properly and gives you a chance to see the condition of the initial connector on the cable plant. It should be long, at least 500 to 1000 meters to be safe, and the connectors on it should be the best possible to reduce reflections. They must also match the connectors being tested, if they use any special polish techniques.



### Features:

- Hard carry case
- The instrument's ergonomic design fits comfortably in hand for extended periods.
- The length of launch cable defined by the customer.
- Various types of optical connectors offer increased versatility and convenience.
- Optical connectors are dust and drop protected by a snap-on cover.

### Specifications:

Parameter	unit	Note
Fiber length	m	$L \pm 50$ m
Connectors Insertion loss	dB	following OPTOKON technical specification according connector type
Connectors Return loss	dB	following OPTOKON technical specification according connector type
Operating Temperature	°C	-20 to + 70
Loss accuracy - SM (1310/1550 nm), MM (850/1300 nm)		
Backscatter measurements 1 dB steps	dB	$\pm 0.05$ dB
Reflectance measurements	dB	$\pm 2.0$ dB

### Ordering code:

<b>OLC</b>	-	<b>AAA</b>	/	<b>AAA</b>	-	<b>XX</b>	-	<b>XXXX</b>
		IN/OUT connector types*				fiber:		length** (m)
						OM1    62.5/125		
						OM2    50/125		
						SM     9/125 (G.652)		
						TW     TrueWave		
						XX     please specify		